PIGTRONIX PHILOSOPHER'S TONE 2

User's Guide



All contents © Bond Audio LLC 2023

CONTENTS

D3

Introduction

04

Explanation of Controls

06

Warranty

07


Contact Information

ENLIGHTENING.

Elevating the groundbreaking optical compression of the original Philosopher's Tone to a new plane of tonal enlightenment, the Philosopher's Tone 2 is a world-class compressor/sustainer with footswitchable Grit, allowing for more versatility than ever before. Featuring a refined implementation of the overdrive circuit first heard in the limited-edition Gold version of this iconic compressor pedal, the unique germanium distortion found in the Philosopher's Tone 2 delivers smooth top end and rich midrange response, tailored to perfectly match the characteristics of the optical sustainer driving it.

In addition to Volume and Sustain controls, the Philosopher's Tone 2 features a parallel clean Blend knob that allows musicians to mix their instrument's original tone with the compressor/sustainer effect when the Grit circuit is bypassed. This mixing technique restores natural pick-attack and allows clean settings with extreme sustain to remain dynamic and musical. When the Grit circuit is engaged, the Blend knob is automatically bypassed, circumventing the compromises of the original unit and imparting a colorful distortion to your sound in both Germanium and Silicon modes.

Depending on the position of the Grit knob, the diode-clipping can provide everything from subtle overdrive to overflowing distortion. A Treble control located just before the master Volume provides 6db of cut or boost at 2kHz for fine-tuning the frequency response of the effect. The Philosopher's Tone 2 features true-bypass switching and internal 18V power rails for maximum clean headroom that is ideal for use with hot pickups, active bass, synthesizers and other line-level sources.



EXPLANATION OF CONTROLS



Footswitches

Engage: Press to engage the Compressor. When turned off, this switch provides True Bypass for the entire unit.

Grit: Press to turn on the Overdrive stage located after the compressor section.

Knobs

2



4

Volume: Sets the overall output volume.

Blend: Mixes your compressed effect with your clean signal. Note: This control is only active when the Grit footswitch is turned OFF.



5 Sustain: Sets the amount of sustain.



Grit: Controls the gain of the overdrive stage. Note: This control is only active when the Grit footswitch is turned ON.



Treble: Boosts or cuts treble at 2kHz.

Rocker Switch



8 Si/Ge: Selects between the linear silicon diode clipping of the original Philosopher's Tone and the non-linear germanium diode clipping of the DUIL of the clipping of the original Philosopher's Tone and the non-linear, germanium diode clipping of the Philosopher's Gold version.

> Philosopher's Tone 2 requires a negative tip, 9VDC power supply. Philosopher's Tone 2 does not take batteries.

PIGTRONIX LIMITED WARRANTY

Your new Pigtronix product is warranted to be free from defects in materials and workmanship for 1 year from the original date of purchase. Warranty applies only to the original retail purchaser of a registered Pigtronix product, subject to the limitations contained in this warranty.

THIS WARRANTY IS EXTENDED TO THE ORIGINAL RETAIL PURCHASER OF PIGTRONIX PRODUCTS BOUGHT ON OR AFTER JANUARY 1, 2020 ONLY AND MAY NOT BE TRANSFERRED OR ASSIGNED TO SUBSEQUENT OWNERS. IN ORDER TO VALIDATE YOUR WARRANTY, AND AS A CONDITION PRECEDENT TO WARRANTY COVERAGE HEREUNDER, YOU MUST REGISTER YOUR PRODUCT WITHIN THIRTY (30) DAYS FOLLOWING THE ORIGINAL DATE OF PURCHASE. YOUR PROOF OF PURCHASE OR SALES RECEIPT MUST ACCOMPANY ALL REQUESTS FOR WARRANTY COVERAGE— YOU MAY SUBMIT YOUR RECEIPT ON THE REGISTRATION FORM. IF YOU DO NOT REGISTER THE PRODUCT WITHIN 30 DAYS OF PURCHASE, YOUR PRODUCT WILL NOT BE SERVICED UNDER WARRANTY.

If your product is destroyed, lost or damaged beyond repair while in the possession of Pigtronix for repair, Pigtronix will replace that product with one of the same or most similar style of a value not in excess of the original purchase price of your pedal. Any insurance covering the pedal, including but not limited to collector's value insurance, must be carried by you at your expense.

This warranty covers the cost of both labor and materials on repairs deemed necessary by our Customer Service Representative.

THIS WARRANTY DOES NOT COVER:

- Any product that has been altered or modified in any way or upon which the serial number has been tampered with or altered.
- Any product whose warranty has been altered or upon which false information has been given.
- Any product that has been damaged due to misuse, negligence, accident, or improper operation.
- The subjective issue of tonal characteristics.
- · Shipping damages of any kind.
- · Any product that has been subjected to extremes of humidity or temperature
- Normal wear and tear
- Any product that has been purchased from an unauthorized dealer, or upon which unauthorized repair or service has been performed.

PIGTRONIX MAKES NO OTHER EXPRESS WARRANTY OF ANY KIND WHATSOEVER. ALL IMPLIED, WARRANTIES, INCLUDING WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, EXCEEDING THE SPECIFIC PROVISIONS OF THIS WARRANTY ARE HEREBY DISCLAIMED AND EXCLUDED FROM THIS WARRANTY. SOME STATES AND/OR COUNTRIES DO NOT ALLOW THE EXCLUSION OR LIMITATION OF IMPLIED WARRANTIES SO THAT THE ABOVE MAY NOT APPLY TO YOU. PIGTRONIX SHALL NOT BE LIABLE FOR ANY SPECIAL, INDIRECT CONSEQUENTIAL, INCIDENTAL OR OTHER SIMILAR DAMAGES SUFFERED BY THE PURCHASER OR ANY THIRD PARTY, INCLUDING, WITHOUT LIMITATION. DAMAGES FOR LOSS OF PROFITS OR BUSINESS OR DAMAGES RESULTING FROM USE OR PERFORMANCE OF THE PRODUCT, WHETHER IN CONTRACT OR IN TORT, EVEN IF PIGTRONIX OR ITS AUTHORIZED REPRESENTATIVE HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES, AND PIGTRONIX SHALL NOT BE LIABLE FOR ANY EXPENSES, CLAIMS, OR SUITS ARISING OUT OF OR RELATING TO ANY OF THE FOREGOING.

Steps To File for Warranty Coverage:

- 1. Register your new guitar at http://pigtronix.com/warranty
- 2. Complete the warranty request form available at **http://pigtronix.com/support** and we will handle it from there!

CONTACT INFORMATION

Address Bond Audio LLC 141 W 28th St, Floor 4 New York, NY, 10001

> **Phone** 631-331-7447

Email info@pigtronix.com Warranty Service Email support@pigtronix.com

Warranty Contact Form

pigtronix.com/warranty

Website pigtronix.com

YouTube youtube.com/pigtronix



Product manuals are offered digitally in an attempt to be mindful of our environment. We ask that you consider the same before printing at home. Thank you!

All contents © Bond Audio LLC 2023